

Policrom Gum Arabic

Description

Policrom Gum Arabic is the finest quality gum arabic.

Directions

As a litho plate preservative, use as-is or mix up to 50/50 with water. Apply liberally to plate and buff dry with clean cloth or sponge.

As a fountain solution additive, add 0.5-2 oz./gallon.

Product Need and Usage

Policrom Gum Arabic is the product of choice for use in the preservation of lithographic plates or as a fountain solution additive.

Features

- * Finest quality gum arabic.
- * Excellent preservative for litho plates.
- * Can be used as a fountain solution additive.
- * Shelf life of 2 years unopened; 6 months opened.

Technical Specifications

Flash Point (° F TCC)	> 200
VOC (lb/gal method 24)	0.00
Specific Gravity	1.10
Water-Miscible	Yes
Color	Clear Amber
Odor/Fragrance	Mild

Rev. 9/13/2016

Disclaimer: Unless otherwise restricted by applicable law, nothing contained in this literature shall be deemed a representation or warranty of any kind, either expressed or implied. See the Safety Data Sheets (SDS) for this product for safety information prior to use.